





WM-46UN-L2 Installation Drawing/取付寸法図 (X463UN)



- 1) This monitor is not symmetrical.
Center line shows image center.
- 2) Dimension (E) shows adjustable range of horizontally.
Dimension (F) shows adjustable range of vertically.
- 3) Monitor position is shown bottom end in adjustable range.

Parts

- ① Wall bracket (top)
- ② Wall bracket (bottom)
- ③ Monitor bracket (top)
- ④ Monitor bracket (bottom)
- ⑤ Adjuster pin
- ⑥ Stopper
- ⑦ Monitor

