





assembly instructions for easyFrame NEC461 landscape screenmode (2x2 / middle-position)




1




BASE in front-position or BASE in middle-position


2




3




4



5



6



7

