

## MultiSync EX Series Dedicated Carrying Case (SC-EX23/SC-EX20) User's Manual

This carrying case is designed to contain a MultiSync EX series monitor with a photo frame stand (ST-EX2023) installed. It is not intended to be used for long time storage. It cannot contain the height-adjustable stand.

### ⚠ Caution

#### Do not place the case near water or in areas exposed to water



Do not expose to water

- Do not use the case in places exposed to water such as the following. To prevent fire or shock hazards, do not put any object containing water on the carrying case.
  - Do not use outside when it is raining or snowing, or in places like the seashore or waterside
  - Do not use in the bathroom
  - Do not put flower pots, plant pots, cups, cosmetics, medicines, etc., on the carrying case

In the event the carrying case has been wet, wait until it is completely dry before using it. Also remove any foreign substance that may enter the case. Storing a LCD monitor when the carrying case is wet or containing a foreign substance may lead to a fire or a shock hazard.

#### When handling the carrying case



Handle with care

- Do not shake or throw the case with a monitor inside. Do not store in the case objects other than LCD monitors and attached accessories, or a stand other than the photo frame stand (ST-EX2023). To avoid malfunction, do not apply excessive force to the monitor. Also be careful not to drop the carrying case, as it may lead to an injury.



Caution

- Place the case on its side to open it.

For other handling precautions, see the User's Manual of the LCD monitor.

### Recommended use


#### • Carrying a LCD monitor

- Pay attention to the monitor's orientation. Store it properly in the case before carrying it.
- Store the monitor properly with LCD panel in contact with the reinforced side inside the case.
- Always secure the monitor with the straps.
- Do not expose the LCD monitor to shock or apply strong pressure on it by shaking, dropping or pressing it, or by putting objects on it.
- Do not use this case to send a monitor through delivery service or freight transportation. It may cause a malfunction.
- If manipulating a damaged LCD panel, pay attention not to get injured with glass fragments. Be also careful not to inhale or swallow liquid crystals that may leak from the panel. They are toxic. In the event they enter your mouth or come into contact with your eyes, rinse with water and consult a physician. If your hands or cloths are stained with liquid crystals, wipe it off with alcohol and wash with water.

#### • Storing a LCD monitor

Place the carrying case on an even surface to open it.

- When storing a LCD monitor in the the carrying case, fold the photo frame stand's foot onto the monitor's body. Storing a monitor with the stand's unfolded may lead to a malfunction.
- Strongly pull the ends of the straps to secure the monitor inside the carrying case with the hook and loop fasteners.
- Store the cabling evenly inside to right and left pockets referring to the figure below. Do not insert more than 3 accessories in a single pocket. They may apply pressure on the monitor and cause a malfunction.
- Make sure to tighten all the fasteners.



## MultiSync EXシリーズ専用キャリングバッグ(SC-EX23/SC-EX20)取扱説明書

このキャリングバッグは、MultiSync EXシリーズにフォトフレームスタンド(ST-EX2023)をつけた状態で持ち運ぶためのものです。長期保管用ではありません。高さ調節機能付き標準スタンドは収納できません。

### ⚠ 注意

#### 水場や水にぬれるような所には置かない



水ぬれ禁止

- 次のような水にぬれるおそれがある所では使用しないでください。  
またキャリングバッグの上に水の入った容器を置かないでください。火災・感電の原因となります。
  - ・ 雨天や降雪時、海岸や水辺で使用しない
  - ・ 風呂やシャワー室で使用しない
  - ・ キャリングバッグの上に花びん、植木鉢、コップ、化粧品、薬品を置かない万ーキャリングバッグがぬれた場合は、乾かしてから使用してください。また、キャリングバッグ内に異物が入った場合は取り除いてください。ぬれたり異物が入ったキャリングバッグに液晶ディスプレイを収納すると、火災・感電の原因となることがあります。

#### キャリングバッグの取り扱いについて



無理な扱いは  
しない

- 液晶ディスプレイを収納して振り回さないでください。また、液晶ディスプレイおよび液晶ディスプレイの添付品以外およびフォトフレームスタンド(ST-EX2023)以外のスタンドは入れないでください。  
液晶ディスプレイに無理な力がかかって故障の原因となったり、キャリングバッグが落下して、けがの原因となることがあります。



注意

- キャリングケースを開ける場合は、横に寝かした状態であけてください。

その他の取り扱い注意は、液晶ディスプレイの取扱説明書を参照してください。

### お願い


#### ● 液晶ディスプレイの持ち運びについて

- ・ 液晶パネルの向きに注意して、キャリングバッグに正しく収納して運んでください。
- ・ キャリングバッグ内の保護面に液晶パネル面が接するように正しく収納してください。
- ・ 固定バンドをかならず使用してください。
- ・ 振り回したり、落としたり、押さえつけたり、上に物を乗せたりして、液晶ディスプレイ本体に強い衝撃や圧力を与えないでください。
- ・ 液晶ディスプレイをキャリングバッグに収納した状態で、宅配便や貨物輸送はしないでください。故障の原因となります。
- ・ 液晶パネルが破損した場合は、ガラスで怪我をしないよう、気をつけて取り扱ってください。また、液晶が漏れ出た場合は、液晶を吸い込んだり、飲んだりすると、中毒を起こす原因になります。万一口に入ってしまったり、目に入ってしまった場合は、水でゆすいでいただき、医師の診断を受けてください。手や衣類についてしまった場合は、アルコールなどで拭き取り、水洗いしてください。

#### ● 液晶ディスプレイの収納について

キャリングバッグを平らな面において開いてください。

- ・ 液晶ディスプレイをキャリングバッグに収納するときは、フォトフレームスタンドの足を本体に接するようにしてください。  
開いたまま収納すると、故障の原因となる場合があります。
- ・ 固定バンドを両側から強く引っ張って、マジックテープで液晶ディスプレイをキャリングバッグに確実に固定してください。
- ・ ケーブル類は図を参照して、左右のポケットにバランスよく入れてください。1つのポケットに4本以上の付属品を入れないでください。付属品が本体を圧迫して故障の原因となる場合があります。
- ・ ファスナーを確実に締めてください。



## MultiSync EX系列专用手提包(SC-EX23/SC-EX20)使用说明书

该手提包是用于携带装入支架(ST-EX2023)的MultiSync EX系列的手提包。  
不用于长期保管。不能存放带有高度调节功能的标准支架。

### ⚠ 注意

#### 请勿放在浸水或淋水的场所



禁止淋水

- 请勿在下述可能会淋水的场所使用。

另外,请勿在手提包上放置盛有水的容器。否则可能会导致火灾、触电。

- 下雨或下雪天时,请勿在海边或河边使用
- 请勿在浴室或淋浴室使用
- 请勿在手提包上放置花瓶、花盆、杯子、化妆品或药品

手提包淋湿时,请先干燥,然后再使用。手提包内进入杂物时,请清除杂物。如果将液晶显示器装入淋湿或进入杂物的手提包中,则可能会导致火灾、触电。

#### 关于手提包的使用



请勿乱扔乱放

- 请勿在装入液晶显示器后甩动手提包。另外,请勿放入液晶显示器及其附件以外的物品,以及支架(ST-EX2023)以外的支架。

如果向液晶显示器施加过大的力,则可能会导致发生故障。如果手提包掉落,则可能会导致受伤。



注意

- 请在放倒的状态下打开手提包。

有关其它使用注意事项,请参阅液晶显示器的使用说明书。

### 要求

#### ● 关于液晶显示器的携带

- 携带之前,请注意液晶面板的方向,正确地装入手提包。
- 请正确地液晶显示器放入手提包内,使液晶面板表面接触手提包内的保护面。
- 请务必使用固定带。
- 请勿甩动、掉落、按压手提包或手提包上放置物品,请勿使液晶显示器主体承受过大的冲击或压力。
- 请勿在手提包内装入液晶显示器的状态下进行送货上门或货物运输。否则可能会导致故障。
- 液晶面板损坏时,请小心处理,以免被玻璃划伤。另外,液晶渗漏时,请注意勿吸入或吞入液晶,否则可能会导致中毒。万一进入嘴里或溅入眼中,请立即用水漱口或冲洗眼睛,然后去医院就医。如果沾在手上或衣服上,请用酒精等擦拭,然后水洗。

#### ● 关于液晶显示器的放入

请在平坦的地方打开手提包。

- 将液晶显示器放入手提包内时,请使支架支脚接触主体。  
如果在打开的状态下放入,则可能会导致故障。
- 请从两侧用力张拉固定带,并利用粘扣将液晶显示器可靠地固定在手提包内。
- 有关电缆类,请参阅图示,平整地将电缆放入左右兜内。请勿在一个兜内放入4件以上的附件。如果附件压迫主体,则可能会导致故障。
- 请可靠地系紧扣件。

