

Plasma Display Unit

Instruction Manual


■ Terminal Cover PX-CV2U

Thank you for your purchase of the NEC Plasma Display Terminal Cover.

Please read this instruction manual carefully as an aid in proper use.


* This plasma display Terminal Cover is for use with only the PX-42VP4, PX-42XM2, PX-50XM3 and PX-61XM2 plasma displays manufactured by NEC.

List of Packaged Parts



Screw Fastening Locations

Please fasten the screws at the positions indicated in the diagram below.



Specifications

Model : PX-CV2U

	Dimensions	Weight
Terminal Cover	93.5 (W) x 455 (H) x 81 (D) mm / 3.7 (W) x 17.9 (H) x 3.2 (D) inches	0.32 kg / 0.71 lbs
Bracket A	33(W) x 333 (H) x 29 (D) mm / 1.3 (W) x 13 (H) x 1.1 (D) inches	0.16 kg / 0.35 lbs
Bracket B	11.7 (W) x 406 (H) x 34.5 (D) mm / 0.5 (W) x 16(H) x 1.4 (D) inches	0.13 kg / 0.29 lbs

Copyright © by NEC Plasma Display Corporation.

NEC and the NEC logo are registered trademarks of NEC Corporation.

Heed the Following

Before Use...

Symbols

Various symbols are used in this Instruction Manual for the safe and proper use of the product as well as preventing any injury or damage to persons or property. These symbols and their meanings are described below. Please have a good understanding of these matters before reading the main text of the manual.

WARNING



Ignoring this indication and improper handling could be the cause of personal injury such as a serious injury or death.

CAUTION



Ignoring this indication and improper handling could cause injury to a person or damage to the surrounding household belongings.

Examples of Symbols



⚠ This symbol informs that there are contents that **demand caution (including warnings)**. Concrete details of the caution are written within the diagram.



⊘ This symbol indicates a **prohibited** matter. Concrete details of the prohibition are written within the diagram.



❗ This symbol indicates something that **must be done**. Concrete details of the prohibition are written within the diagram.



WARNING



* Be sure to have your store of purchase install your plasma display and adjust its angle. If the plasma display is improperly installed, it may fall or tip over and cause injury.



* To ensure safety, tighten bolts and screws securely. If bolts and screws are not securely tightened, the plasma display may fall or tip over and cause injury.



* Do not modify any parts. Doing so could cause the plasma display to fall or tip over and cause injury.



* Do not use damaged parts. Doing so could cause the plasma display to fall or tip over and cause injury. If a part should be damaged, contact your store of purchase.



* This unit is exclusively for use with NEC PX-42VP4, PX-42XM2, PX-50XM3 and PX-61XM2 plasma displays. Do not use it with other devices.

CAUTION

-  - Do not obstruct the plasma display's ventilation holes. If the ventilation holes are obstructed, heat will build up inside, possibly leading to fire. Do not for example install the plasma display in a tight place where ventilation is poor, place a cover over it, etc.
-  - Do not install the plasma display near air conditioner air outlets or in places where it will be exposed to vibration. Doing so could result in fire or electric shock.
-  - Do not install the plasma display in humid or dusty places or in places where it will be exposed to soot or steam (on kitchen counters, near humidifiers, etc.). Doing so could lead to fire. Do not use outdoors. Doing so could result in fire or electric shock.
-  - When installing the plasma display, leave space of at least 50 cm around it. Failure to leave enough space will cause heat to build up inside, possibly leading to fire.
-  - Do not apply force to the glass surface of the plasma display. The glass could break, resulting in injury.
-  - Never use any screws other than those included. Doing so could result in damage.

Installation Location

Avoid rooms with a lot of dust, humidity, greasy smoke, or tobacco smoke.

Dirt will adhere to the surface of the display monitor screen and cause a deterioration in image quality.

Avoid places in which the screen is exposed to direct sunlight or illumination light.

When surrounding light hits the screen directly, the image appears washed out and is difficult to view.


Avoid places which reach high temperatures or low temperatures.

Such extreme temperatures will cause breakdown.


Mounting the Terminal cover on the plasma display

Mounting on the PX-42VP4 or PX-42XM2


- 1.** Remove the two screws in the positions shown on the diagram from the plasma display.




- 2.** Fasten fitting bracket A using the screws removed in step 1.




- 3.** Loosen the two screws in the positions shown on the diagram from the plasma display without removing them.




- 4.** After installing and wiring the plasma display, slide fitting bracket B to catch it on the screws loosened above, then tighten the screws.



- 5.** Insert the Terminal cover onto fitting bracket A.




- 6.** Screw the Terminal cover to fitting bracket B using the included screws and fasten.




Mounting the Terminal cover on the plasma display

Mounting on the PX-50XM3


- 1.** Remove the two screws in the positions shown on the diagram from the plasma display.




- 2.** Line up the terminal board with the surface of fitting bracket A as shown in the diagram, then fasten fitting bracket A with the screws removed in step 1.




- 3.** Loosen the two screws in the positions shown on the diagram from the plasma display without removing them.




- 4.** After installing and wiring the plasma display, slide fitting bracket B to catch it on the screws loosened above, then tighten the screws.



- 5.** Insert the Terminal cover onto fitting bracket A.




- 6.** Screw the Terminal cover to fitting bracket B using the included screws and fasten.




Mounting the Terminal cover on the plasma display

Mounting on the PX-61XM2


- 1.** Remove the two screws in the positions shown on the diagram from the plasma display.




- 2.** Line up the terminal board with the surface of fitting bracket A as shown in the diagram, then fasten fitting bracket A with the screws removed in step 1.




- 3.** Loosen the two screws in the positions shown on the diagram from the plasma display without removing them.



- 4.** After installing and wiring the plasma display, slide fitting bracket B to catch it on the screws loosened above, then tighten the screws.



- 5.** Insert the Terminal cover onto fitting bracket A.



- 6.** Screw the Terminal cover to fitting bracket B using the included screws and fasten.

